

Defender
Smart & Safe Living

Defender
Smart & Safe Living

Alarm System User Manual



- Ver. 3.0 Voice Plus
- Ver. 4.0 Voice Plus



Specifications are subject to change without notice.
Defender is a registered trademark of defender Co, Ltd. Other brands and product names are trademarks of their respective holders.
Copyright @ 2009. All rights reserved.




Defender Co, Ltd.

Monitor • Control • Surveillance

For Your Safety

Before operating the system, please confirm the correct input power voltage.



The lightning flash with an arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

INFORMATION - This equipment has been tested and found to comply with limits of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated

WARNING - Do not change or modify any parts or component used and approved by the manufacturer.

WARNING - To prevent electric shock and risk of fire hazards:
Do NOT use power sources other than that specified.
Do NOT expose this appliance to rain or moisture.

This installation should be made by a qualified service person and should conform to all local codes.

Defender Alarm Shortcut Key

- Away Arm: Press Button A for 3 Sec
- Home Arm: Press Button H for 3 Sec
- Disarm: Press (4 Digit Password)
- Bypass Zone: Press *(4 Digit Password)(No of Zone)#
- Change Password: Press *6(4 Digit Password)0
(New 4 Digit Password)(New 4 Digit Password)
- Tel No Setting: Press *7(4 Digit Password)1(Tel. No)#
1 for setting User 1, 2 for User 2, 3 for User 3, 4 for User 4

Telephone Control Manual

4 Digit Password is 1234

- Press 0 to Disarm
- Press 1 to Arm
- Press 2 for Home Automation Control
- Press 3 for Bypass Setting
- Press 4 for Panic Alarm
- Press # to Exit

System Installation Information

[illegible]

Timer

Entry Time [_____]

Exit Time [_____]

Bell Cut Off Time [_____]

Telephone

Number of ring before answer [_____]

Each number well be dial

1 [_____]

$$2[\text{_____}]$$

3 [_____]

4 [_____]

Warning & Cautions

This information is provided to ensure your safety and to prevent any losses. Please read it carefully and use the product accordingly.

*For product inquiries, please contact the retail shop where you bought the system.

- Please make sure the product is installed at proper place to insure system operate properly.

Warning/Attention/Special Mark Messages



Ignoring this information may
result in death or serious personal injuries.



Ignoring this information may
result in material loss or personal injuries.



Indicates "Never Allowed."



Indicates "No Disassembling."



Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)

Applicable in the European Union and other European countries with separate collection systems)


This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Precautions

Do not install system under extreme temperature conditions or in high humidity environment.



Use only under temperature conditions between -10°C and $+50^{\circ}\text{C}$.
Provide good ventilation when using in high temperature conditions.

LIMITED WARRANTY

Manufacturer warrants original purchaser twelve months from the date of purchase, the product shall be free of defects in materials and workmanship under normal use. During the warranty period, manufacturer, at its option, repair or replace any defective product upon return of the product to its factory.

International Warranty

The warranty for international customers is the same as for any customers within Malaysia, with the exception that manufacturer shall not be responsible for any customs fees, taxes, or VAT that may be due.

Conditions to Void Warranty

This warranty applies only to defects in parts and workmanship relating to normal use. It does not cover:

- damage incurred in shipping, handling, improper maintenance or improper application.
- damage caused by disaster such as fire, flood, wind, earthquake or lightning.
- damage due to causes beyond the control such as excessive voltage, mechanical shock or water damage.
- damage caused by unauthorized attachment, alterations, modifications or foreign objects.
- damage caused by peripherals.
- defects caused by failure to provide a suitable installation environment for the products.
- damage caused by use of the products for purposes other than those for which it was designed.

Out of Warranty Repairs

Manufacturer will at its option repair or replace out-of-warranty products which are returned to its factory according to the following conditions. Anyone returning goods to Manufacturer must first obtain an authorization number. Manufacturer will not accept any shipment whatsoever for which prior authorization has not been obtained. Product which Factory determines to be repairable will be repaired and returned. Products which factory determines not to be repairable will be replaced by the nearest equivalent product available at that time. The current market price of the replacement product will be charged for each replacement unit for the case is determined out of warranty.

Maintenance

The system requires minimum maintenance.

1. Do not wash the keypad with a wet cloth. Light dusting with a barely damp cloth should remove normal accumulations of dust.
2. It is recommended that the standby battery be replaced every year.

WARNING

This system is an advanced security system, it does not offer guaranteed protection against burglary, fire or other emergency. Whether commercial or residential.

Remember

Intruders may gain access through unprotected openings or have the technical sophistication to bypass an alarm sensor or disconnect an alarm warning device. Intrusion detector (e.g. passive infrared detectors), smoke detectors, and any many other sensing devices will not work without power.

Battery-operated devices will not work without batteries, with dead batteries, or if the batteries are not put in properly. Some device may have sensing limitations.

Components and Accessories



1. PC BOX



2. Keypad



3. Mother Board



4. Transformer



5. Resistor



6. Fuse (1A)



7. Fuse (2A)



8. User Manual

About Your Security System

This equipment has been designed to give the highest flexibility and convenience. Read this manual carefully and have you installer instruct you on system operation and on which features have been implemented in your system.

Important Notice

To ensure that you system continues to functions as intended, it is important that you check & test your system every 2 weeks.

If your system does not function properly, call your installer for service.

A security system cannot prevent emergencies.

Remember it is only intended to alert you and, monitoring of an emergency situation.

This security systems is reliable but may not work under all conditions and not substitute for prudent security practices of life and property insurance.

Your security systems should be installed and serviced by qualified security professionals who should instruct you on the level of protection that has been provided and on system operations.

The image shows a web-based configuration interface titled "Defender Network Configuration". It contains a yellow header bar with the title. Below the header, there is a text box stating "This page allows the configuration of the board's network settings." followed by a red-bordered box with a "CAUTION" message: "Incorrect settings may cause the board to lose network connectivity. Recovery options will be provided on the next page." Below this, it says "Enter the new settings for the board below:". The main configuration area has several input fields: "IP Address:" with the value "192.168.1.10", "Gateway:" with "192.168.1.1", "Subnet Mask:" with "255.255.255.0", "Primary DNS:" with "169.254.1.1", and "Secondary DNS:" with "0.0.0.0". There is an unchecked checkbox labeled "Enable DHCP". To the right of the checkbox, a callout box says "Un-tick because using static IP". Another callout box points to the IP address field, saying "192.168.1.10 static IP address". At the bottom of the configuration area are two buttons: "Save Config" and "cancel".

Figure 10.6

c. If want to change back to Dynamic DHCP after Static, just tick the ENABLE DHCP at Network configuration then follow the steps in 4.0 (b).

5.0 Default factory setting

- If unable to connect to DSA due to incorrect setting, user can reset DSA to factory default setting.
- Turn off the DSA power, then press the reset button and turn on the power. Continue pressing the button until the LED flashes release the button.

6.0 Security Features

- For security purpose, the browser will auto logout after some time. This is because user might forget to logout.

9.0 Default factory setting

- a. If any mistake cause the DSAW unable to connect, set to factory default setting is needed.
- b. Off the DSAW power, press the reset button and on the power, continue holding the button until the LED flash then release the button.
- c. After reset, the DSAW network setting was returned to default factory setting and the Username was reset.

10.0 Security of DSAW

- a. For security purpose, the DSAW will auto logout to login page after some time when do some instructions.
- b. If access the DSAW by illegal (without login the username and password), the information of defender smart alarm will hide or automatically return back to login page.

SUMMARY OF SYSTEM

Central Features

- 2 Programmable Partitions
- 2 Programmable phone numbers for CMS reporting
- 2 Programmable account numbers for CMS reporting
- 2 Arm Modes: Away & Home
- 8 Full programmable zone

Speech Dialer

- Support 4 programmable phone numbers for voice messages reporting.
- Only master code holder has full access to phone remote operation.

Keypad

- Support up to 4 keypads per system

Access Code

- Support 3 level authorizations: Installer, Master, User
- Support 1 installer code, 1 master code, 8 user code
- Default installer code is [1397]
- Default master code is [1234]

Remote Operation Functions Include

- Secure remote communications using security codes
- Remote operation via touch / mobile phone
- Zone status check
- Arm & Disarm
- Zone bypass
- Home automation control

PROGRAMMING THE CONTROL PANEL

- The programming menu can only be accessed when the control panel is fully disarmed

To Enter The Programming Menu

- Press [*] [o] follow by [installer code] to access the system programming menu.
- Key in the address code 2 digit [] []
- To exit the programming menu, press [#]

To Set The Entry Time

- Press [*] [o] follow by [installer code] to access the system programming menu
- Press [40]
- Enter the entry timer [] [] []
- Press [#] to save & exit programming menu

To Set The Exit Time

- Press [*] [o] follow by [installer code] to access the system programming menu
- Press [42]
- Enter the exit timer [] [] []
- Press [#] to save & exit programming menu

To Set The Silent Zone

- Press [*] [o] follow by [installer code] to access the system programming menu
- Press [16]
- Enter the zone number
- Press [#] 2 time to save & exit programming menu

To Activate The Remote Control

Press [*] [0] follow by [installer code] to access the system programming menu,
Press [33]
Light on the zone 7 and zone 8 LED,
Press [#] 2 time to save & exit programming menu.

To Reset Panel

Press [*] [0] follow by [installer code] to access the system programming menu,
Press [99]
Press [#] 2 time to save & exit the programming menu.

To Change The Sensitivity of Zone Respond

Press [*] [0] follow by [installer code] to access the system programming menu,
press [45]
Enter the value [] [] [] [],
Example: High sensitive [001], low sensitive [255]
Press [#] to save & exit programming menu.

To Change Master Code

The system must be disarm,
Press [*] [6] follow by old master code [1234] (default)
Press [0]
Enter new master code for 2 time [xxxx] [xxxx] (4 digit)

To Add User Code

The system must be disarm,
Press [*] [6] follow by [master code] (4 digit)
Press user number [x], maximum can set up to 8 user
Enter new user code for 2 time [xxxx] [xxxx] (4 digit)

To Add The Phone Number


The system must be disarm,
Press [*] [7] follow by [master code] (4 digit)
Press user number [x], maximum can set up to 4 user
Press the user phone number []
Press [#] after finish, to save & exit Programming menu.

To Delete The Phone Number

Press [*] [7] follow by [master code] (4 digit)
Press user number [x], which want to delete
Press [#] to save & exit Programming menu.


To Turn On / Off The Chime Mode

The system must be disarm,
Press [*] [81]
Press [zone number] which want to on/off chime mode.
Press [#] to save & exit programming menu.



The image shows a 'Defender Network Configuration' window with a yellow title bar. At the top, a pink box contains a caution: 'CAUTION: Incorrect settings may cause the board to lose network connectivity. Recovery options will be provided on the next page.' Below this is a form with several fields: 'Enable DHCP' (checked), 'IP Address: 192.168.1.2', 'Gateway: 192.168.1.1', 'Subnet Mask: 255.255.255.0', 'Primary DNS: 169.254.1.1', 'Secondary DNS: 0.0.0.0', and 'Port Number: 8080'. An arrow points from the text 'New Port Number' to the 'Port Number' field. At the bottom of the form are 'Save' and 'cancel' buttons.

Figure 8.1 Network Setting



```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\USER>nbtstat -R
Successful purge and preload of the NBT Remote Cache Name Table.

C:\Documents and Settings\USER>ping defender

Pinging defender [192.168.1.2] with 32 bytes of data:

Reply from 192.168.1.2: bytes=32 time=1ms TTL=100
Reply from 192.168.1.2: bytes=32 time=1ms TTL=100
Reply from 192.168.1.2: bytes=32 time=1ms TTL=100
Reply from 192.168.1.2: bytes=32 time=1ms TTL=100

Ping statistics for 192.168.1.2:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 1ms, Average = 1ms

C:\Documents and Settings\USER>
```

Figure 8.2 Command Prompt

c. Open the browser and key in <http://defender:8080>. Successfully accessed the login page was shown. Refer to figure 3.0.

6.0 Configuration DSAW's Port number

a. Refer to figure 8.0, the default DSAW's port number was assigned as 8088.

Defender Network Configuration

CAUTION: Incorrect settings may cause the board to lose network connectivity. Recovery options will be provided on the next page.

☒ Enable DHCP

IP Address: 192.168.1.2

Gateway: 192.168.1.1

Subnet Mask: 255.255.255.0

Primary DNS: 169.254.1.1

Secondary DNS: 0.0.0.0

Port Number: 8088

Save

cancel

Figure 8.0 Network Setting

- b. To update the new port number, just key in the new port number at Port Number text box (figure 8.1). A reboot message was shown at figure 7.3 after Save button was pressed.
- i. Follow the reboot message, close the browser and open the command prompt. If users used window vista or window 7 (latest OS), please open the command prompt as "run as administrator".
- ii. Key in "nbtstat -R" command. "Successful purge and preload of the NBT Remote Cache Name Table" message was shown at figure 8.2.
- iii. Key in "ping defender" command to ping DSAW. A successfully reply message was shown at figure 8.2.

To Bypass Zone

The system must be disarm,
Press [*] [4] follow by [master code]
The **BYPASS LED** will turn on
Enter the zone number to by passed.
Press [#] to save & exit programming menu.
(The LED at zone that is bypass will **Keep Flashing**)

To Unbypass Zone

The system must be disarm,
Press [*] [4] follow by [master code]
The **BYPASS LED** will turn on
Enter the zone number to unbypass.
Press [#] to save & exit programming menu.
(The LED at zone that is unbypass will **Stop Flashing**)

To Set The System Time

The system must be disarm,
Press [*] [1] follow by [master code]
Press [30]
Enter the time [HHMM]
Press [#] to save & exit Programming menu.


To Set The System Date

The system must be disarm,
Press [*] [1] follow by [master code]
Press [31]
Enter the date [DDMM]
Press [#] to save & exit programming menu.

To Set The System Year

The system must be disarm,
Press [*] [1] follow by [master code]
Press [32]
Enter the Year [YYYY]
Press [#] to save & exit Programming menu.

Control Panel Layout



Version 3

- c. If users want to change back to Dynamic DHCP after Static, just tick the *ENABLE DHCP* at Network configuration then save.
 - i. The Reboot message was shown in the browser (figure 6.1).
 - ii. Then followed the step 6.0.b.
 - iii. to 6.0.b.
 - vii. Successfully result was shown at figure 6.4 and figure 6.5.

```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\USER>nbtstat -R
    Successful purge and preload of the NBT Remote Cache Name Table.

C:\Documents and Settings\USER>ping defender

Pinging defender [192.168.1.2] with 32 bytes of data:
Reply from 192.168.1.2: bytes=32 time=1ms TTL=100
Reply from 192.168.1.2: bytes=32 time=1ms TTL=100
Reply from 192.168.1.2: bytes=32 time=1ms TTL=100
Reply from 192.168.1.2: bytes=32 time=1ms TTL=100

Ping statistics for 192.168.1.2:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 1ms, Average = 1ms

C:\Documents and Settings\USER>_
```

Figure 6.4 Command Prompt

Defender Network Configuration

CAUTION: Incorrect settings may cause the board to lose network connectivity. Recovery options will be provided on the next page.

☒ **Enable DHCP**

IP Address:

Gateway:

Subnet Mask:

Primary DNS:

Secondary DNS:

Port Number:

Figure 6.5 Network Setting

- iii. Follow the reboot message, close the browser and open the command prompt. If users used window vista or window 7 (latest OS), please open the command prompt as “run as administrator”.
- iv. Key in “**nbtstat -R**” command. “Successful purge and preload of the NBT Remote Cache Name Table” message was shown at figure 6.2.
- v. Key in “**ping defender**” command to ping DSAW. A successfully reply message was shown at figure 6.2 with new Static IP address (192.168.1.10).

```

C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\USER>nbtstat -R
    Successful purge and preload of the NBT Remote Cache Name Table.

C:\Documents and Settings\USER>ping defender

Pinging defender [192.168.1.10] with 32 bytes of data:

Reply from 192.168.1.10: bytes=32 time=2ms TTL=100
Reply from 192.168.1.10: bytes=32 time=1ms TTL=100
Reply from 192.168.1.10: bytes=32 time=1ms TTL=100
Reply from 192.168.1.10: bytes=32 time=1ms TTL=100

Ping statistics for 192.168.1.10:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 2ms, Average = 1ms

C:\Documents and Settings\USER>

```

Figure 6.2 Command Prompt

- vi. DSAW have been successfully configured to static IP address. Open the browser and login to DSAW by key in <http://defender:8088>. (Figure 3.0).
- vii. Go to the Network setting, the updated information was shown at figure 6.3.

Defender Smart Alarm

Defender Network Configuration

CAUTION: Incorrect settings may cause the board to lose network connectivity. Recovery options will be provided on the next page.

Un-tick because in static

☐ Enable DHCP

IP Address: 192.168.1.10 ← 192.168.1.10 static IP address

Gateway: 192.168.1.1

Subnet Mask: 255.255.255.0

Primary DNS: 169.254.1.1

Secondary DNS: 0.0.0.0

Port Number: 8088

Save

cancel

Figure 6.3 Network Setting

1. Zone input 1 to 8

Terminal is use for connect the sensor or detector such as magnetic, vibration or PIR sensor with 1K resistor.

2. Keypad Connector

Terminal is provide connection for the keypad, can connect up to 4 keypad at the same time to control at differ place.

3. Pcom

Terminal is provide 12v power positive to the device that require 12v power.

4. P2 & P1

Terminal is use for Home Automation Output, to drive auxiliary devices such as LED or Relay.

5. Siren

Terminal is use to connect to the siren negative.

6. Tel Out

Terminal is for other telephone extension sockets.

7. Tel In

Terminal is for incoming phone line.

8. Earth Ground Connection

Terminal is to earth or an earth rod.

9. Ac Input

Terminal is for 16v transformer.

10. Remote control

Terminal is use to connection the remote control use to activate the alarm thought the remote control.


11. Web Server

Terminal is use to connection the web server module.

12. Hard Reset

Terminal is use to restore the panel to the defaults setting, need to connection the pin 2 and pin 3 together at the web server port and power up the panel power.

Control Panel Layout



Version 4

5.0 Instruction to configure DSAW as Static IP

a. Default DSAW's network setting assigned to DHCP.

b. Refer to figure 2.0, the DSAW's IP address was assigned by router as 192.168.1.2 in Dynamic DHCP. If users want to assign DSAW as static IP address, please follow below instructions:

- Go to Network Setting, un-tick the ENABLE DHCP and assigned a new IP address (for example: 192.168.1.10) then click Save.

Figure 6.0 Network Setting

- The Reboot message was shown in the browser (figure 6.1).

Figure 6.1 Reboot message

d. Password Setting (figure 4.4)

- Maximum 4 digits numeric

USER	PASSWORD	NOTE
1	1111	To enable the button SET Please key in 4 digits for each user password and same password are forbidden
2	2222	
3	3333	
4	4444	
5	5555	
6	6666	
7	7777	
8	8888	

SET

cancel

Figure 4.4 Password Setting

e. Status Log (Figure 4.5)

- Reload button - for reload the latest information. Maximum show 1000 events, after 1000 events, the next events will show at first location.

Date/Time	Event	Description
11/10/2010 10:19	Remote Disarm	Partition 1 User 3
11/10/2010 10:19	Remote Arm	Partition 1 User 3
11/10/2010 10:19	Remote Disarm	Partition 2 User 2
11/10/2010 10:19	Remote Disarm	Partition 1 User 2
11/10/2010 10:19	Remote Arm	Partition 2 User 2
11/10/2010 10:19	Remote Arm	Partition 1 User 2
11/10/2010 10:09	Remote Disarm	Partition 2 Master
11/10/2010 10:09	Remote Disarm	Partition 1 Master
11/10/2010 10:09	Remote Arm	Partition 2 Master
11/10/2010 10:09	Remote Arm	Partition 1 Master
11/10/2010 10:01	Periodic Test Report	-
11/10/2010 09:25	24 Hour (safe) Alarm	Partition 2 Zone 8
11/10/2010 09:21	Remote Disarm	Partition 2 Master
11/10/2010 09:21	Remote Disarm	Partition 1 Master
11/10/2010 09:21	Remote Arm	Partition 2 Master

Reload

cancel

Figure 4.5 Status Log

1. Zone input 1 to 8

Terminals use for connect the sensor or detector such as magnetic, vibration or PIR sensor

2. Keypad Connector

Terminals provide connection for the keypad, can connect up to 4 keypad at the same time to control at differ place

3. +13

Terminals provide 13v power positive, use to supply remote control power and external siren power only can't connect with strobe light.

4. +12

Terminals provide 12v power positive to the device that require 12v power.

5. P2 & P1

Terminals use for Home Automation Output, to drive auxiliary devices such as LED, Sounder or Relay.

6. Siren

Terminals use to connect to the siren negative.

7. Tel Out

Terminals for other telephone extension sockets.

8. Tel In

Terminals for incoming Phone line

9. Earth Ground Connection

Terminals to earth or an earth rod

10. Ac Input

Terminals for 16v transformer

11. Wireless Module

Terminals use to connection the wireless module

12. Remote control

Terminals use to connection the remote control, to activate the alarm through the remote control.


13. Web Server

Terminals use to connection the web server module

14. Hard Reset

Terminals use to reset the program to defaults setting, need to connection the pin2 and pin3 together at the web server port and power up the panel power.

REMOTE CONTROL CONNECTION LAYOUT



+V & -V - connect to 12V DC power supply.

1 S - Connect 1 S to zone 8


2 S - Connect 2 S to pin number 2

Com - Connect com to pin number 1

(1 S is use for panic button)

(2 S is use for Arm and Disarm System)

KEYPAD CONNECTION LAYOUT



ZONE PROGRAMMING

Zone Type	Address Zone	Default Zone Type							
		1	2	3	4	5	6	7	8
Delay	10	•							
Internal Delay	11		•						
Internal	12								
Instant	13			•	•	•	•	•	
24 Hour	14								•
Fire	15								
Silent	16								
Normally Open	17								
Zone Respond	18								
Intelligent Zone 1	19								
Intelligent Zone 2	20								
Zone Partition1	21	•	•	•	•	•	•	•	•
Zone Partition2	22								
Auto Reset Zone	23	•	•	•	•	•	•	•	•
CMS Zone Report	24	•	•	•	•	•	•	•	•
Partition 1 user	25	•	•	•	•	•	•	•	•
Partition 2 user	26								

(• is default setting)

4.1 Configuration DSAW

a. Zone setting (Figure 4.1)

- Location – name the location for each zone (max 10 characters).
- Camera Link – IP camera web link for each zone (max 40 characters).

Defender Alarm Board Configuration

Alarm Sensor Zone

ZONE	LOCATION	CAMERA LINK
ZONE 1	Garden	<input type="text" value="http://www.zonelink1.com.my"/>
ZONE 2	Dining	<input type="text" value="http://www.zonelink2.com.my"/>
ZONE 3	Kitchen	<input type="text" value="http://www.zonelink3.com.my"/>
ZONE 4	Fence	<input type="text" value="http://www.zonelink4.com.my"/>
ZONE 5	Corridor	<input type="text" value="http://www.zonelink5.com.my"/>
ZONE 6	Hall	<input type="text" value="http://www.zonelink6.com.my"/>
ZONE 7	Front Door	<input type="text" value="http://www.zonelink7.com.my"/>
ZONE 8	Back Door	<input type="text" value="http://www.zonelink8.com.my"/>

Alarm Light Zone

LIGHT ZONE	LOCATION
ZONE 1	<input type="text" value="Inside"/>
ZONE 2	<input type="text" value="Outside"/>

save

cancel

Figure 4.1 Zone setting

b. Refer to figure 4.0.

- Status – condition for each zone in Arm, Trigger, Ready, Open or Bypass status.
- Last Trigger – indicate which zone was triggered after disarm.
- Camera Link – IP camera link for each zone.
- Bypass – indicate which zones have been bypass.

c. Functionality of DSAW.

- ARM – to arm the alarm system
- DISARM – to disarm the alarm system
- BYPASS – to set or clear the zone bypass

d. Configuration of DSAW (only master authenticate)

- Zone Setting – to define zone location and IP Camera Link for each zone.
- Timer Setting – auto arm or disarm the alarm system and auto turn on or off the light follow timer (24 hour format).
- Network Setting – Configure DSAW's network setting in Dynamic (IP address assign by router) or Static (IP address assign by user) and Port number.
- Password Setting – change the user's login password (only 4 digits acceptable).
- Status Log – to indicate who and what activities done on DSAW.
- Logout – logout the DSAW.

Technical Data

Delay - The zone will not cause an alarm during the entry / exit delay time.

Internal Delay - The zone will not cause an alarm during the delay time at Away mode and will not cause an alarm during home mode.

Internal - The zone will not cause an alarm during home arm mode.

Instant - The zone will cause an instant alarm when the system is arm.

24 Hour - The zone will cause instant alarm regardless of system arm / disarm.

Fire - The zone will cause a unique alarm with distinctive 'fire' tone if it is violated regardless of system arm / disarm

Silent - The siren will not sound when the zone open.

Normally Open Zone - The zone can be assign to normally open or normally close

Zone Respond - Have 2 different respond time: 'on' mean slow respond, 'off' mean fast respond.

Intelligent Zone 1 & 2 - The zone will not trigger siren before the zone counter and zone reset timer expires.

Zone Partition 1 & 2 - Partition allow the system to be divided into areas of protection so that different partition can be arm and disarm independently from each other.

Auto Reset Zone - The zone will restore and become normal after the bell time.

CMS Zone Report - The panel will report the zone status to the CMS center

Partition 1 & 2 User - To assign the user to access the partition.

(Default: All user can access to partition 1 only)

SYSTEM SETTING

CMS Reporting	Address	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
	30	●	●	●	●	●	●	●	

Zone 1 - Report Panic

Zone 2 - Report Duress

Zone 3 - Report Arm / Disarm

Zone 4 - Report AC Fail

Zone 5 - Report enter / exit programming mode

Zone 6 - Report Telephone line fault

Zone 7 - Report Bypass

Zone 8 - Report Battery low

Technical Data

Report Panic

On - The panel will report panic to the centre

Off - The panel will not report panic to the centre

Report Duress

On - The panel will report Duress to the centre

Off - The panel will not report Duress to the centre

Report Arm / Disarm

On - The panel will report Arm / Disarm to the centre

Off - The panel will not report Arm / Disarm to the centre

Report AC Fail

On - The panel will report AC Fail to the centre

Off - The panel will not report AC Fail to the centre

Report Enter / Exit Programming Mode

On - The panel will report Enter / Exit programming to the centre

Off - The panel will not report Enter / Exit programming to the centre

Report Telephone Line Fault

On - The panel will report telephone line fault to the centre

Off - The panel will not report telephone line fault to the centre

Report Bypass

On - The panel will report Bypass to the centre

Off - The panel will not report Bypass to the centre

Report Battery low

On - The panel will report battery low to the centre

Off - The panel will not report battery low to the centre

Communicator Setting	Address	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
	31	●			●		●		

Zone 1 - Enable personal resporting

Zone 2 - Enable CMS resporting

Zone 4 - Enable Fix line

Zone 6 - Enable skip password protect

Technical Data

Enable personal resporting

On - The panel will report the event to the user

Off - The panel will not report the event to the user

Enable CMS resporting

On - The panel will communicate with the CMS centre

Off - The panel will not communicate with the CMS centre

Enable Fix line

On - The panel will communicate using telephone line

Off - The panel will not communicate using telephone line

Enable Skip password protect

On - When call out the user don't have to key in password

Off - When call out the user have to key in password

System Option	Address	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
	33	●	●	●	●	●	●	●	

Zone 1 - Keypad buzzer on during entry delay

Zone 2 - Keypad buzzer on during exit delay

Zone 4 - DTMF dialing

Zone 5 - Arm using H or A

Zone 6 - Panic button P

Zone 7 - Remote control

Zone 8 - Bell squawk

Keypad buzzer on during entry delay

On - The keypad will produce the entry tones

Off - Entry tones will not produce

Keypad buzzer on during exit delay

On - The keypad will produce the exit tone

Off - Exit tone will not produce

DTMF dialing

On - The panel will dial using DTMF tone

Off - The panel will dial using older pulse tone

Arm using H or A

On - Enable arm using H or A key

Off - Disable arm using H or A key

Button P

On - Enable using button P for panic button

Off - Disable using panic button

Remote Control

On - The panel will Enable remote control

Off - Disable remote control

Bell Squawk

On - The panel siren will pulsed once when the system is arm, pulsed twice when the system is disarm

Off - The siren will behaves normally on arm and disarm

4.0 8 zones alarm panel status

a. The status of 8 zones home alarm panel status will shown as below after login (Figure 4.0).

ZONE	STATUS	LAST TRIGGER	CAMERA LINK	BYPASS
Zone 1	Ready		Camera Link	Set/Clear
Garden				
Zone 2	Ready		Camera Link	Set/Clear
Dining				
Zone 3	Ready		Camera Link	Set/Clear
Kitchen				
Zone 4	Ready		Camera Link	Set/Clear
Fence				
Zone 5	Ready		Camera Link	Set/Clear
Corridor				
Zone 6	Ready		Camera Link	Set/Clear
Hall				
Zone 7	Ready		Camera Link	Set/Clear
Front Door				
Zone 8	Ready		Camera Link	Set/Clear
Back Door				




Figure 4.0 Defender 8 zone alarm panel status

- b. Username maximum can be register with **8 characters**.
- c. Username can be register as alphanumeric with uppercase or lowercase.




Figure 3.2

- d. The username only can be registered one time only, after successfully registered username it will automatically link to login page (gure 3.2).
- e. If users forget the username, it need to power off the web server. Than press the button on web server while it is turn on and keep pressing for 5 seconds.
- f. After successfully reset the username, it will automatically link to login page (gure 3.1).

Time Setting	Address	Default Value	Unit
Entry 1	40	040	sec
Entry 2	41	040	sec
Exit 1	42	120	sec
Exit 2	43	120	sec
Bell Time	44	005	minute
Fast respond	45	008	ms
Slow respond	46	015	ms
Intelligent counter 1	47	002	times
Intelligent counter 2	48	003	times
Intelligent reset timer 1	49	010	minute
Intelligent reset timer 2	50	030	minute
Home Automation 1	51	103	manual trigger
Home Automation 2	52	103	manual trigger
Keypad lock digit	55	032	times
Keypad lock time	56	060	sec
Communicator dialing time	57	040	sec
Communicator idle time	58	100	sec
Communicator dial loop	59	003	times
Answer ring	60	006	ring
Communicator password error auto hang up	61	020	times
CMS periodic report	62	024	hour

Technical Data

Entry 1 - The system uses this timer to allow the user time to access the keypad and disarm partition 1.

(Can be set from 000 to 255 sec)

Entry 2 - The system uses this timer to allow the user time to access the keypad and disarm partition 2.

(Can be set from 000 to 255 sec)

Exit 1 - This timer controls the delay between the user initiating the exit procedure for partition 1.

(Can be set from 000 to 255 sec)

Exit 2 - This timer controls the delay between the user initiating the exit procedure for partition 2.

(Can be set from 000 to 255 sec)

Bell Time - This timer controls the duration of the bell output after an alarm has occurred.

(Can be set from 000 to 255 minute)

Fast respond - If a zone is programmed with the 'fast respond' attribute, the zone respond will be controlled by the duration of this timer.

(Can be set from 001 to 255 x 1.6ms)

Slow respond - If a zone is programmed with the 'slow respond' attribute, the zone respond will be controlled by the duration of this timer.

(Can be set from 001 to 255 x 1.6ms)

Intelligent counter - The intelligent Zone only cause alarm if trigger many times and exceed intelligent counter value within intelligent reset time.

Home Automation - Use for connection to household appliances.

Keypad Lock Digit - The keypad will auto lock if key in the wrong password.

(Can be set from 000 to 255 time)

Keypad lock time - The keypad will auto unlock when the lock time exceed.

(Can be set from 000 to 255 sec)

Communicator dialing time - Time to wait for the user to answer during personal reporting.

Communicator idle time - Time to wait for key press before auto hang up during personal reporting.

Communicator dial loop - Number of time to redial on each telephone number.

Answer ring - Number of ring required in order to answer the incoming call.

(Can be set from 000 to 255 ring)

Communicator password error auto hang up - Number of incorrect password digit allowed before communicator auto hang up.

CMS periodic report - This timer controls the CMS periodic report interval time.

Programming	Address	Default Value
CMS Account Number 1	70	0000
CMS Account Number 2	71	0000
CMS Phone Number 1	72	-
CMS Phone Number 2	73	-
Change Installer Code	76	1397
Reset user Code	98	-
Reset panel	99	-

Technical Data

CMS Account Number - The panel will communicate with Centre Monitoring Station (CMS) using the account number

CMS Phone Number - The panel can call CMS using phone numbers. The primary number will be dialled first (secondary telephone number is backup number for the primary number)

Change Installer Code - the default installer code is 1397. To change the installer code, the new installer code must be key in 2 times.

Reset User Code - The panel will delete all the user code. Master code will change to default password, that is '1234'

Reset Panel - All the programming and password will change to default value.

HOME AUTOMATION TIMER

Enter Programming Menu,

[*] [1] [Mater code] [Address] [Time]

System	Address	Format
System Time	30	HHMM
System Date	31	DDMM
System Year	32	YYYY
Auto Arm Partition 1	33	HHMM
Auto Disarm Partition 1	34	HHMM
Auto Arm Partition 2	35	HHMM
Auto Disarm Partition 2	36	HHMM
Night Mode begin time	37	HHMM
Night Mode end time	38	HHMM
Control Timer 1 on	39	HHMM
Control Timer 1 off	40	HHMM
Control Timer 2 on	41	HHMM
Control Timer 2 off	42	HHMM
Auto Off timer	43	Minute

Technical Data

System Time - The option allow you to set the system time.

System Date - The option allow you to set the system date.

System Year - The option allow you to set the system year.

Auto Arm Partition - The system will auto arm the selected partition.

Auto Disarm Partition - The System will auto disarm the selected partition.

Night Mode Time - The option allow you to set the night mode time.

Control Timer On - Home automation on according to user setting time.

Control Timer Off - Home automation off according to user setting time.

Auto Off Timer - Home automation will auto turn off after exceed user setting time.

b. Open the browser login to DSAW. Key in <http://defender:8088>. Login page will show as below (Figure 3.0).

Figure 3.0 Login Page

3.0 Register New Username

a. To register new username, please enter the IP address as

<http://defender:8088/protect/register.htm>. Figure 3.1.

Figure 3.1

Defender Smart Alarm Webserver (DSAW)

A device that allow user to check the home status and control the alarm system functionality through a web page via Ethernet.


1.0 Hardware – Default Factory Setting

MAC Address	- C8:1E:8E:00:00:00
IP Address	- 169.254.1.1
Gateway	- 169.254.1.1
Subnet Mask	- 255.255.0.0
Primary DNS	- 169.254.1.1
Secondary DNS	- 0.0.0.0
Port	- 8088
Web Server Username-	admin
Password	- 1234

2.0 Communication between DSAW and home user Router

a. Home user Router will automatically assign a Dynamic IP address to DSAW (figure 2.0).

Example: TP-LINK ROUTER (TD-W8901G) with DSAW.



TP-LINK®

DHCP IP Pool Summary

Host Name	IP Address	MAC Address	Expire Time
	192.168.1.2	C8-1E-8E-00-00-47	2days, 23:58:45
oem-adc4936ff0a	192.168.1.3	00-E0-4C-77-36-54	2days, 23:53:42

Assign by router (pointing to 192.168.1.2) DSA Mac Address (pointing to C8-1E-8E-00-00-47)

Figure 2.0: DSAW's IP address assigned by TP-link router as 192.168.1.2

Home Automation	Value
Zone Open Without Auto Off Feature	000 - 007
Zone Open With Auto Off Feature	016 - 023
Zone Open without Auto Off Feature during Night Mode	032 - 039
Zone Open with Auto Off Feature during Night Mode	048 - 055
Control follow Timer 1	064
Control follow Timer 2	065
Control follow Timer 1 & 2	066
Activate during away arm without auto off feature	067
Activate during away arm with auto off feature	068
Activate during away arm without auto off feature during Night Mode	069
Activate during away arm with auto off feature during Night Mode	070
Activate follow zone trigger	071 - 079
Activate follow zone trigger (Pulse signal)	087 - 094
Manual On/ Off	103
Activate when trouble condition exist	105
Activate when fully arm	104
Activate when zone trigger auto off after time exceed	106
Activate when zone trigger auto off after disarm	107

Technical Data

Activate when zone open without auto off feature - Activate when zone open and deactivate manually

Zone 1 - 000	Zone 3 - 002	Zone 5 - 004	Zone 7 - 006
Zone 2 - 001	Zone 4 - 003	Zone 6 - 005	Zone 8 - 007

Activate when zone open with auto off feature - Activate when zone open and deactivate when the auto off time exceed

Zone 1 - 016	Zone 3 - 018	Zone 5 - 020	Zone 7 - 022
Zone 2 - 017	Zone 4 - 019	Zone 6 - 021	Zone 8 - 023

Control timer 1 - The home automation output will activate follow control timer 1.

Control timer 2 - The home automation output will activate follow control timer 2.

Control timer 1 & 2 - The home automation output will activate follow control timer 1 & 2.

Activate during entry / exit time without auto off feature - Activate when system arm deactivate by manually.

Activate during entry / exit time with auto off feature - The home automation output will pulse 1 second when the system is arm, pulse 2 second when the system is disarm.

Follow zone trigger - Activate when zone trigger and deactivate when system disarm.

Manual On / Off - It can be turn on or off manually through keypad, telephone or internet.

Activate when full arm - It will activate the system is arm, deactivate when system is disarm.

Activate when trouble condition exit - Activate when the panel detect trouble.

Activate when zone trigger auto off after time exceed - It will only function when the system is arm, activate when zone trigger Auto off after timer exceed.

Activate when zone trigger auto off after disarm - It will only function when the system is arm, activate when zone trigger Auto off after disarm.

Keypad Command Summary

To disarm the system	Press [master code]
To arm in home mode	Press [H] 3 sec to arm all the partition in home mode
To arm in away mode	Press [A] 3 sec to arm all the partition in away mode
To bypass zone	Press [*] [4] [master code] [zone] [#]
Display memory	Press [*] [5]
Change master code	Press [*] [6] [master code] [0] [new master code 2 time]
Add user code	Press [*] [6] [master code] [user number] [new user code 2 time]
Add duress code	Press [*] [6] [master code] [9] [new duress code 2 time]
Delete user code	Press [*] [6] [master code] [user number] [*]
Set phone number	Press [*] [7] [master code] [user] [phone number] [#]
Display trouble	Press [*] [50] 1. AC Fail 7. Time Fail 2. Battery Low 8. Date Fail 3. CMS Fail
Chime mode	Press [*] [81] [zone number]
Walk test	Press [*] [82] [zone number]
Testing CMS	Press [*] [83]
Home automation	Press [*] [9] [1] on/off home automation 1 [2] on/off home automation 2 [5] on all home automation [6] off all home automation
To exit	Press [#]

Technical Data

Default master code [1234]

Maximum 8 user code, 1 master code and 1 duress code, Max. 4 user phone number

Smart Dialer Operation Summary

Key	Status
0	Disarm System
1	Arm System
2	Home Automation
3	Bypass Zone
4	Panic Alarm
8	Check Alarm Manu
9	Repeat Alarm Status
#	Hang up

Partition Summary

To arm / disarm the system	Press [master code] [0] arm / disarm all the partition Press [master code] [1] arm / disarm partition 1 Press [master code] [2] arm / disarm partition 2
To arm in home mode	Press [H] 3 sec to arm all the partition in home mode
To arm in away mode	Press [A] 3 sec to arm all the partition in away mode
To bypass zone	Press [*] [4] [master code] [zone] [#]
Display memory	Press [*] [5]
Change master code	Press [*] [6] [master code] [0] [new master code 2 time]
Add user code	Press [*] [6] [master code] [user number] [new user code 2 time]
Add duress code	Press [*] [6] [master code] [9] [new duress code 2 time]
Delete user code	Press [*] [6] [master code] [user number] [*]
Set phone number	Press [*] [7] [master code] [user] [phone number] [#]
Display trouble	Press [*] [50] 1. AC Fail 7. Time Fail 2. Battery Low 8. Date Fail 3. CMS Fail
Chime mode	Press [*] [81] [zone number]
Walk test	Press [*] [82] [zone number]
Testing CMS	Press [*] [83]
Home automation	Press [*] [9] [1] on/off home automation 1 [2] on/off home automation 2 [5] on all home automation [6] off all home automation
To exit	Press [#]

Technical Data

Default master code [1234]

Maximum 8 user code, 1 master code and 1 duress code

Maximum 4 user phone number

Smart Dialer Operation Summary

Key	Status
0	Disarm System
1	Arm System
2	Home Automation
3	Bypass Zone
4	Panic Alarm
8	Check Alarm Manu
9	Repeat Alarm Status
#	Hang up